



新發興機械（馬）有限公司

Sin Huat Hin Machinery (M) Sdn. Bhd.

241232-A E-Mail:shhmach@tm.net.my

Home Page: <http://www.shhmach.com> SINCE 1968



ELECTRONIC CRANE SCALE



SWHS - 0050 - 1000



SWHS - 2000 - 20000



**DEFEND HIGH
HOT CRANE SCALE**

- Weight accumulation function
- HOLD function
- Gross/Net weight display convertible
- Auto shut off function
- 30mm high LED/LCD display digit
- Remote control calibration
- Easy to replace battery
- AC/DC power adaptor: output DC9V/1.5A
- 6V/7Ah rechargeable scaled leadacid battery Remote distance min: 105m

SPECIFICATION

Model No.	Max Cap	Graduation	A (mm)	B (mm)	C (mm)	Net Weight
SWHS - 0050	50kg	0.02 kg	350	80	20	4.0kg
SWHS - 0100	100kg	0.05 kg	350	80	20	4.0kg
SWHS - 0200	200kg	0.1 kg	350	80	20	4.0kg
SWHS - 0300	300kg	0.1 kg	350	80	20	4.0kg
SWHS - 0500	500kg	0.2 kg	370	85	30	4.5kg
SWHS - 1000	1000kg	0.5 kg	370	85	30	4.5kg
SWHS - 2000	2000kg	1.0 kg	600	80	45	14.0kg
SWHS - 3000	3000kg	1.0 kg	600	80	45	14.0kg
SWHS - 5000	5000kg	2.0 kg	730	100	55	24.0kg
SWHS - 10000	10000kg	5.0 kg	850	120	70	44.0kg
SWHS - 15000	15000kg	5.0 kg	900	140	70	60.0kg
SWHS - 20000	20000kg	10.0 kg	900	140	70	60.0kg
DEFEND HIGH HOT CRANE SCALE						
SWHS - 1000	1000 kg	0.5 kg	420	65	35	12 kg
SWHS - 2000	2000 kg	1.0 kg	600	80	45	14 kg
SWHS - 3000	3000 kg	1.0 kg	730	100	55	24 kg
SWHS - 5000	5000 kg	2.0 kg	850	120	70	44 kg
SWHS - 10000	10000 kg	5.0 kg	900	140	70	60 kg
SWHS - 15000	15000 kg	10.0 kg	900	140	70	60 kg

ACCESSORY



Adapter



Remote Control

Head Office & Workshop, Showroom

No. 697, Taman Chip Aik, Jalan Tun Dr. Ismail, 70200 Seremban, N.S.D.K., Malaysia.

Tel: 606 - 7653338
Tel: 606 - 7653339

Fax: 606 7653334
Fax: 606 7628188

KL Branch Office

No. B1-00-20 Jln. SR 1/9, Tmn. Serdang Raya, Sri kembangan 43300 Serdang Jaya, selangor D.E., Malaysia.

Tel: 603-89425711

Fax: 603-89483151